Inspiring Innovation • Persistent Perfection

English

All-in-one PC

User Manual

ET24 Series

English

E5916

First Edition V1
July 2010

Copyright © 2010 ASUSTeK COMPUTER INC. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTeK COMPUTER, INC. ("ASUS").

Products and corporate names mentioned in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used for identification purposes only. All trademarks are the property of their respective owners.

Every effort has been made to ensure that the contents of this manual are correct and up to date. However, the manufacturer makes no guarantee regarding the accuracy of its contents, and reserves the right to make changes without prior notice.

Contents

Notices 5
Federal Communications Commission Statement 5
Canadian Department of Communications Statement 6
IC Radiation Exposure Statement for Canada 6
Declaration of Conformity (R&TTE directive 1999/5/EC) 6
CE Mark Warning 7
Wireless Operation Channel for Different Domains 7
France Restricted Wireless Frequency Bands 8
REACH 9
Global Environmental Regulation Compliance and Declaration 10
Takeback Services 10
Notes for this manual 11
Safety information 12
Setting up your system 12
Care during use 12
Welcome 13
Package contents 13
Getting to know your All-in-one PC 14
Front view 14
Rear view 16
Side views 18
Using the touch screen 20
Showing the touch pointer 20
Cleaning the touch screen 21
Using the keyboard 22
Function keys 23
Positioning your All-in-one PC 24
Placing on the desktop 24
Mounting to the wall 25
Setting up your All-in-one PC 27
Connecting the wired keyboard and mouse 27

English

Connecting the wireless keyboard and mouse 27
Powering on the system 28
Powering off 28
Configuring a wireless connection 29
Configuring a wired connection 30
Using a static IP 30
Using a dynamic IP (PPPoE) 32
Configuring the audio output 35
Speaker configurations 35
Connecting to speakers 35
Configuring audio output settings 36
Overclocking your All-in-one PC 37
Replacing or upgrading memory 38
Recovering your system 39
Using the hidden partition 39
Recovering the OS to the Factory Default Partition (F9 Recovery) 39
Backing up the Factory Default Environment Data to a USB Drive (F9 Backup) 39
Using the USB storage device (USB Restore) 40

Notices

Federal Communications Commission Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Canadian Department of Communications Statement

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.

IC Radiation Exposure Statement for Canada

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with IC RF exposure compliance requirements, please avoid direct contact to the transmitting antenna during transmitting. End users must follow the specific operating instructions for satisfying RF exposure compliance.

Operation is subject to the following two conditions:

- This device may not cause interference and
- This device must accept any interference, including interference that may cause undesired operation of the device.

Declaration of Conformity (R&TTE directive 1999/5/EC)

The following items were completed and are considered relevant and sufficient:

- Essential requirements as in [Article 3]
- Protection requirements for health and safety as in [Article 3.1a]
- Testing for electric safety according to [EN 60950]
- Protection requirements for electromagnetic compatibility in [Article 3.1b]
- Testing for electromagnetic compatibility in [EN 301 489-1] & [EN 301 489-17]
- Effective use of the radio spectrum as in [Article 3.2]
- Radio test suites according to [EN 300 328-2]

CE Mark Warning

This is a Class B product, in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

CE marking for devices without wireless LAN/Bluetooth

The shipped version of this device complies with the requirements of the EEC directives 2004/108/EC "Electromagnetic compatibility" and 2006/95/EC "Low voltage directive".

CE marking for devices with wireless LAN/ Bluetooth

This equipment complies with the requirements of Directive 1999/5/EC of the European Parliament and Commission from 9 March, 1999 governing Radio and Telecommunications Equipment and mutual recognition of conformity.

Wireless Operation Channel for Different Domains

N. America	2.412-2.462 GHz	Ch01 through CH11
Japan	2.412-2.484 GHz	Ch01 through Ch14
Europe ETSI	2.412-2.472 GHz	Ch01 through Ch13

France Restricted Wireless Frequency Bands

Some areas of France have a restricted frequency band. The worst case maximum authorized power indoors are:

- 10mW for the entire 2.4 GHz band (2400 MHz–2483.5 MHz)
- 100mW for frequencies between 2446.5 MHz and 2483.5 MHz

Channels 10 through 13 inclusive operate in the band 2446.6 MHz to 2483.5 MHz.

There are few possibilities for outdoor use: On private property or on the private property of public persons, use is subject to a preliminary authorization procedure by the Ministry of Defense, with maximum authorized power of 100mW in the 2446.5–2483.5 MHz band. Use outdoors on public property is not permitted.

In the departments listed below, for the entire 2.4 GHz band:

- Maximum authorized power indoors is 100mW
- Maximum authorized power outdoors is 10mW

Departments in which the use of the 2400–2483.5 MHz band is permitted with an EIRP of less than 100mW indoors and less than 10mW outdoors:

01 Ain	02 Aisne	03 Allier	05 Hautes Alpes	
08 Ardennes	09 Ariège	11 Aude	12 Aveyron	16 Charente
24 Dordogne	25 Doubs	26 Drôme	32 Gers	36 Indre
37 Indre et Loire	41 Loir et Cher	45 Loiret	50 Manche	55 Meuse
58 Nièvre	59 Nord	60 Oise	61 Orne	63 Puy du Dôme
64 Pyrénées Atlantique	66 Pyrénées Orientales		67 Bas Rhin	68 Haut Rhin
70 Haute Saône	71 Saône et Loire		75 Paris	82 Tarn et Garonne
84 Vaucluse	88 Vosges		89 Yonne	
90 Territoire de Belfort	94 Val de Marne			

This requirement is likely to change over time, allowing you to use your wireless LAN card in more areas within France. Please check with ART for the latest information (www.art-telecom.fr)

Your WLAN Card transmits less than 100mW, but more than 10mW.

NO DISASSEMBLY

The warranty does not apply to the products that have been disassembled by users

Lithium-Ion Battery Warning

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

No Exposure to Liquids

DO NOT expose to or use near liquids, rain, or moisture. This product is not waterproof or oil-proof.

This symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment, and mercury-containing button cell battery) should not be placed in municipal waste. Check local regulations for disposal of electronic products.

DO NOT throw the battery in municipal waste. The symbol of the crossed out wheeled bin indicates that the battery should not be placed in municipal waste.

REACH

Complying with the REACH (Registration, Evaluation, Authorization, and Restriction of Chemicals) regulatory framework, we publish the chemical substances in our products at ASUS REACH website at http://csr.asus.com/english/REACH.htm.

TV Tuner Notices

Note to CATV System Installer—Cable distribution system should be grounded (earthed) in accordance with ANSI/NFPA 70, the National Electrical Code (NEC), in particular Section 820.93, Grounding of Outer Conductive Shield of a Coaxial Cable – installation should include bonding the screen of the coaxial cable to the earth at the building entrance.

Global Environmental Regulation Compliance and Declaration

ASUS follows the green design concept to design and manufacture our products, and makes sure that each stage of the product life cycle of ASUS product is in line with global environmental regulations. In addition, ASUS disclose the relevant information based on regulation requirements.

Please refer to http://csr.asus.com/english/Compliance.htm for information disclosure based on regulation requirements ASUS is complied with:

Japan JIS-C-0950 Material Declarations
EU REACH SVHC
Korea RoHS
Swiss Energy Laws

Takeback Services

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for our customers to be able to responsibly recycle our products, batteries and other components as well as the packaging materials. Please go to http://csr.asus.com/english/Takeback.htm for detail recycling information in different region.

Notes for this manual

To ensure that you perform certain tasks properly, take note of the following symbols used throughout this manual.

WARNING: Vital information that you MUST follow to prevent injury to yourself.

IMPORTANT: Instructions that you MUST follow to complete a task.

TIP: Tips and useful information that help you complete a task.

NOTE: Additional information for special situations.

All illustrations and screenshots in this manual are for reference only. Actual product specifications and software screen images may vary with territories. Visit the ASUS website at www.asus.com for the latest information.

English

Safety information

Your All-in-one PC ET24 Series is designed and tested to meet the latest standards of safety for information technology equipment. However, to ensure your safety, it is important that you read the following safety instructions.

Setting up your system

- Read and follow all instructions in the documentation before you operate your system.
- Do not use this product near water or a heated source such as a radiator.
- Set up the system on a stable surface.
- Openings on the chassis are for ventilation. Do not block or cover these openings. Ensure that you leave plenty of space around the system for ventilation. Never insert objects of any kind into the ventilation openings.
- Use this product in environments with ambient temperatures between 0˚C and 40˚C.
- If you use an extension cord, ensure that the total ampere rating of the devices plugged into the extension cord does not exceed its ampere rating.

Care during use

- Do not walk on the power cord or allow anything to rest on it.
- Do not spill water or any other liquids on your system.
- When the system is turned off, a small amount of electrical current still flows. Always unplug all power, modem, and network cables from the power outlets before cleaning the system.
- The touch screen requires periodic cleaning to achieve the best touch sensitivity. Keep the screen clean from foreign objects or excessive dust accumulation. To clean the screen:
    - Turn off the system and disconnect the power cord from the wall.
    - Spray a small amount of a household glass cleaner onto the supplied cleaning cloth and gently wipe the screen surface.
    - Do not spray the cleaner directly on the screen.
    - Do not use an abrasive cleaner or a coarse cloth when cleaning the screen.
- If you encounter the following technical problems with the product, unplug the power cord and contact a qualified service technician or your retailer.
    - The power cord or plug is damaged.
    - Liquid has been spilled into the system.
    - The system does not function properly even if you follow the operating instructions.
    - The system was dropped or the cabinet is damaged.
    - The system performance changes.

Welcome

Congratulations on your purchase of All-in-one PC ET24 Series. The following illustration displays the package contents of your new product. If any of the following items is damaged or missing, contact your retailer.

Package contents

		
All-in-one PC ET24 Series	**Keyboard (wired or wireless)**	**Mouse (wired or wireless)**
		
AC adapter	**Power cord**	**Quick start guide**
		
Warranty card	**TV USB dongle (optional)**	**KBM USB receiver dongle (optional)**

Note:

1. **The number and content of the discs may vary with territories.**
2. **The keyboard, mouse, power supply, TV USB dongle, and KBM USB receiver dongle illustrations are for reference only. Actual product specifications may vary with territories.**

Getting to know your All-in-one PC

Front view

Refer to the following diagram to identify the components on this side of the system.



1 **Webcam**

The built-in webcam with the built-in digital microphone allows you to start video chats online.

2 **LCD display (Touch-enabled function on selected models)**

The 23.6-inch LCD display, with an optimal resolution of 1600 x 900 or 1920 x 1080, features touch function that brings digital life to your fingertips.

3 **Audio Speaker**

The built-in stereo speaker system allows you to hear audio without additional attachments. The multimedia sound system features an integrated digital audio controller that produces rich, vibrant sound (results improved with external stereo headphones or speakers). Audio features are software controlled.

English

Rear view

Refer to the following diagram to identify the components on this side of the system.



1 **DCIN Power input (DC 19V)**

The supplied power adapter converts AC power to DC power for use with this jack. Power supplied through this jack supplies power to the PC. To prevent damage to the PC, always use the supplied power adapter.

The power adapter may become warm or hot when in use. Do not cover the adapter and keep it away from your body.

2 **LAN port**

The eight-pin RJ-45 LAN port supports a standard Ethernet cable for connection to a local network.

3 **HDMI In Port (on selected models)**

HDMI (High-Definition Multimedia Interface) is an uncompressed all-digital audio/video interface between any audio/video source, such as a set-top box, DVD player.

4 **Display (Monitor) Input (on selected models)**

The display input port supports a standard VGA cable and helps turn your All-in-one PC into a larger display for your Notebook PC or other devices.

5 **Antenna Input (on selected models)**

The antenna input is for TV frequency signal and allows for use with the digital TV antenna or input from subscription television services. The antenna can receive digital TV. Cable service connection can receive digital TV, analog TV, depending on paid services.

6 **USB port**

The Universal Serial Bus (USB) port is compatible with USB devices such as keyboards, mouse devices, cameras, and hard disk drives.

The USB ports may support USB 2.0 or USB 3.0 specifications depending on your model.

The number of the USB ports varies with models.

English

Side views

Refer to the following diagrams to identify the components on both sides of the system.



1 **Memory card reader**

Normally an external memory card reader must be purchased separately in order to read memory cards. This All-in-one PC has a built-in memory card reader that supports SD cards used in devices like digital cameras, MP3 players, mobile phones, and PDAs.

2 **USB port**

The Universal Serial Bus (USB) port is compatible with USB devices such as keyboards, mouse devices, cameras, and hard disk drives.

3 **Microphone jack**

The microphone jack is designed to connect a microphone used for video conferencing, voice narrations, or simple audio recordings.

4 **Headphone/Audio Out jack**

The stereo headphone jack (3.5mm) is used to connect the system's audio out signal to amplified speakers or headphones. Using this jack automatically disables the built-in speakers.

5 **Optical Drive**

The built-in optical drive may support compact discs (CD) and/or digital video discs (DVD), and may have recordable (R) or re-writable (RW) capabilities. See the marketing specifications for details on each model.

6 **Power switch**

The power switch allows you to switch the system ON/OFF.

7 **Up Button**

Press to display the volume or brightness menu directly. Or use it to scroll up when navigating other menus.

The button definition varies with models.

8 **Menu Button**

Press to display the main menu.

The menu options vary with models.

9 **Down Button**

Press to display the source or volume menu directly. Or use it to scroll down when navigating other menus.

The button definition varies with models.

English

Using the touch screen

All-in-one PC brings digital life to your fingertips. With a few touches, you can make All-in-one PC work at your command. Your touch functions like a mouse device:

- Touch = left-click on the mouse
- Touch and hold = right-click on the mouse



The touch-enabled screen is available on selected models.

Showing the touch pointer

The touch pointer, virtual mouse, helps you use the touch-enabled screen more conveniently. To show the touch pointer

1. From the Windows® desktop, click **Start** > **Control Panel** > **View Devices and Printer**.



2. Click **Change touch input settings**.


Control Panel ▸ Hardware and Sound ▸
Control Panel Home
System and Security
Network and Internet
Hardware and Sound
Programs
User Accounts and Family Safety
Appearance and Personalization
Clock, Language, and Region
Ease of Access
Devices and Printers
Add a device | Add a printer | Add a Bluetooth device | Mouse | Device Manager
AutoPlay
Change default settings for media or devices | Play CDs or other media automatically
Sound
Adjust system volume | Change system sounds | Manage audio devices
Power Options
Change power-saving settings | Change what the power buttons do
Require a password when the computer wakes | Change when the computer sleeps | Choose a power plan
Display
Make text and other items larger or smaller | Adjust screen resolution | Connect to an external display
How to correct monitor flicker (refresh rate)
Pen and Touch
Change tablet pen settings | Change settings for handwriting personalization | Turn flicks on and off
Set flicks to perform certain tasks | Change touch input settings
Tablet PC Settings
Calibrate the screen for pen or touch input | Set tablet buttons to perform certain tasks
Choose the order of how your screen rotates | Specify which hand you write with
Realtek HD Audio Manager

3. Click the **Touch** tab on the top and click the box before **Show the touch pointer when I'm interacting with items on the screen**. Click **OK** to finish the configuration.



4. You will see a virtual mouse on the screen when you touch the screen.

Cleaning the touch screen

The touch screen requires periodic cleaning to achieve the best touch sensitivity. Keep the screen clean from foreign objects or excessive dust accumulation. To clean the screen:

- Turn off the system and disconnect the power cord from the wall.
- Spray a small amount of a household glass cleaner onto the supplied cleaning cloth and gently wipe the screen surface.
- Do not spray the cleaner directly on the screen.
- Do not use an abrasive cleaner or a coarse cloth when cleaning the screen.

English

Using the keyboard

Your All-in-one PC comes with a wired or wireless keyboard that facilitates your control of the system.

The following keyboard illustration is for reference only. Actual product specifications may vary with territories.





Function keys

The following table defines the colored function keys on the keyboard. To access the colored commands, hold the **Function key** while pressing a key with a colored command.

The actual colored function keys and supported commands may vary with models.

	Fn + F1: Places the system in suspend mode.
	Fn + F2: Toggles the internal wireless LAN or Bluetooth (on selected models) ON or OFF with an on-screen-display. When enabled, the corresponding wireless indicator will light. Windows software settings are necessary to use the wireless LAN or Bluetooth.
	Fn + F5: Decreases the display brightness.
	Fn + F6: Increases the display brightness.
	Fn + F7: Toggles the LCD display ON and OFF.
	Fn + F10: Toggles the speakers ON and OFF.
	Fn + F11: Decreases the speaker volume.
	Fn + F12: Increases the speaker volume.
	Fn + Space (Super Hybrid Engine key): Switches among different power saving modes. The selected mode is shown on the display.
	**Fn + V:** Toggles the built-in webcam ON and OFF.

English

Positioning your All-in-one PC

Placing on the desktop

Place your All-in-one PC on a flat surface such as a table or desk, pull the stand open, and tilt the display panel to an angle of between 12 and 25 degrees from an upright position.

When you tilt the display panel to the angle of 12 degree, a click sound indicates that the display panel is at the proper angle. Avoid the angle less than 12 degree to prevent the display panel from falling forward.



Mounting to the wall

To mount your All-in-one PC to the wall, purchase the optional wall mount pad adapter, wall mount pad and a wall mount kit. Install the wall mount pad according to the following instructions.

The following instructions are for reference only. The actual installation procedures may vary depending on your purchased wall mount kit.

1. Remove the four screws on the stand to release the stand. Keep the screws for future use in case you want to reinstall the stand.



2. Align the wall mount pad adapter to the holes at the back of the All-in-one PC and install it. Secure the pad adapter with four screws.



3. Secure the wall mount pad to the pad adapter with the four screws noting the correct orientation.



4. Hook your All-in-one PC to the wall mount kit securely.

The wall mount kit in this illustration is for reference only.



5. Fasten the wall mount kit to the wall following the instructions described in the installation manual that came with your wall mount kit package.

For ventilation's sake, ensure that you leave a distance of 6cm at least between the system and the wall.

Setting up your All-in-one PC

Connecting the wired keyboard and mouse

Connect the keyboard to the **USB** port on the rear panel (1). You may also connect the keyboard to the **USB** port on the left side if the keyboard cable is not long enough. Then, connect the mouse to the keyboard **USB** port (2).



Connecting the wireless keyboard and mouse

1. Install batteries to the wireless keyboard and mouse.
2. Plug the wireless dongle for keyboard and mouse to a USB port.
3. Push the buttons at the back of both the keyboard and mouse to connect with the All-in-one PC.
4. You can begin using the wireless keyboard and mouse.



The illustrations above are for reference only. Actual appearances and specifications (wired or wireless) of the keyboard and mouse may vary with territories.

English

Powering on the system

Connect the supplied AC adapter to the **DC IN** jack on the rear panel (1 2 3) and then press the **Power switch** on the right (4) to turn on the system.



WARNING! DO NOT connect the AC power cord to an AC outlet prior to connecting the DC plug to the system. Doing so may damage the AC-DC adapter.

Powering off

- To power off the LCD display, press the **Fn + F7 key** Fn F7 on the keyboard. The system is still running.

The colored key command is available on selected models.

- To put the system into suspend mode, press the **Power switch** ⏻ on the right. To bring the system back to the OS, press the **Power switch** again, click the mouse, touch the display, or press any key on the keyboard.
- To shut down the system completely, follow the normal Windows shutdown process.

Configuring a wireless connection

1. Click the wireless network icon with an orange star in the Windows® Notification area.

2. Select the wireless access point you want to connect to from the list and click **Connect** to build the connection.

If you cannot find the desired access point, click the **Refresh** icon on the upper right corner to refresh and search in the list again.

Enter the network security key when connecting to a security-enabled network.



3. After a connection has been established, the connection is shown on the list.
4. You can see the wireless network icon in the Notification area.

English

Configuring a wired connection

Using a static IP

1. Click the network icon with a yellow warning triangle in the Windows® Notification area and select **Open Network and Sharing Center**.



> Ensure that you have connected the LAN cable to the All-in-one PC.

2. Click **Change adapter settings** in the left pane.


Network and Internet ▸ Network and Sharing Center
Search Control Panel
Control Panel Home
Manage wireless networks
Change adapter settings
Change advanced sharing settings
View your basic network information and set up connections
See full map
ASUS-PC (This computer)
Unidentified network
Internet
View your active networks
Connect or disconnect
Unidentified network
Public network
Access type: No Internet access
Connections: Local Area Connection
Change your networking settings
Set up a new connection or network
Set up a wireless, broadband, dial-up, ad hoc, or VPN connection; or set up a router or access point.
Connect to a network
Connect or reconnect to a wireless, wired, dial-up, or VPN network connection.
Choose homegroup and sharing options
Access files and printers located on other network computers, or change sharing settings.
Troubleshoot problems
Diagnose and repair network problems, or get troubleshooting information.
See also
HomeGroup
Internet Options
Windows Firewall

3. Right-click **Local Area Connection** and select **Properties**.



4. Click **Internet Protocol Version 4(TCP/IPv4)** and click **Properties**.


Local Area Connection Properties
Networking
Connect using:
Atheros AR8132 PCI-E Fast Ethernet Controller
Configure...
This connection uses the following items:
Client for Microsoft Networks
Trend Micro NDIS 6.0 Filter Driver
QoS Packet Scheduler
File and Printer Sharing for Microsoft Networks
Internet Protocol Version 6 (TCP/IPv6)
Internet Protocol Version 4 (TCP/IPv4)
Link-Layer Topology Discovery Mapper I/O Driver
Link-Layer Topology Discovery Responder
Install...
Uninstall
Properties
Description
Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.
OK
Cancel

5. Select **Use the following IP address**.
6. Enter your **IP address**, **Subnet mask**, and **Default gateway**.
7. If needed, enter the **Preferred DNS server** address.
8. After entering all the related values, click **OK** to finish the configuration.


Internet Protocol Version 4 (TCP/IPv4) Properties
General
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.
Obtain an IP address automatically
Use the following IP address:
IP address:
Subnet mask:
Default gateway:
Obtain DNS server address automatically
Use the following DNS server addresses:
Preferred DNS server:
Alternate DNS server:
Validate settings upon exit
Advanced...
OK
Cancel

English

Using a dynamic IP (PPPoE)

1. Repeat steps 1–4 in the previous section.
2. Select **Obtain an IP address automatically** and click **OK**.


Internet Protocol Version 4 (TCP/IPv4) Properties
General
Alternate Configuration
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.
Obtain an IP address automatically
Use the following IP address:
IP address:
Subnet mask:
Default gateway:
Obtain DNS server address automatically
Use the following DNS server addresses:
Preferred DNS server:
Alternate DNS server:
Validate settings upon exit
Advanced...
OK
Cancel

(Continue the following steps if using PPPoE)

3. Return to the **Network and Sharing Center** and then click **Set up a new connection or network**.


Network and Internet ▸ Network and Sharing Center
Search Control Panel
Control Panel Home
Manage wireless networks
Change adapter settings
Change advanced sharing settings
View your basic network information and set up connections
See full map
ASUS-PC (This computer)
Unidentified network
Internet
View your active networks
Connect or disconnect
Unidentified network
Public network
Access type: No Internet access
Connections: Local Area Connection
Change your networking settings
Set up a new connection or network
Set up a wireless, broadband, dial-up, ad hoc, or VPN connection; or set up a router or access point.
Connect to a network
Connect or reconnect to a wireless, wired, dial-up, or VPN network connection.
Choose homegroup and sharing options
Access files and printers located on other network computers, or change sharing settings.
Troubleshoot problems
Diagnose and repair network problems, or get troubleshooting information.
See also
HomeGroup
Internet Options
Windows Firewall

4. Select **Connect to the Internet** and click **Next**.


Set Up a Connection or Network
Choose a connection option
Connect to the Internet
Set up a wireless, broadband, or dial-up connection to the Internet.
Set up a new network
Configure a new router or access point.
Manually connect to a wireless network
Connect to a hidden network or create a new wireless profile.
Connect to a workplace
Set up a dial-up or VPN connection to your workplace.
Set up a dial-up connection
Connect to the Internet using a dial-up connection.
Next
Cancel

5. Select **Broadband (PPPoE)** and click **Next**.


Connect to the Internet
How do you want to connect?
Wireless
Connect using a wireless router or a wireless network.
Broadband (PPPoE)
Connect using DSL or cable that requires a user name and password.
Show connection options that this computer is not set up to use
Help me choose
Cancel

6. Enter your User name and, Password, and Connection name. Click **Connect**.



7. Click **Close** to finish the configuration.


Connect to the Internet
The connection to the Internet is ready to use
To connect to the Internet next time, left-click the network icon in the taskbar and click the connection you just created.
Close

8. Click the network icon in the notification area and click the connection you just created.



9. Enter your user name and password. Click **Connect** to connect to the Internet.



Configuring the audio output

All-in-one PC supports different types of audio configurations. Set up the system using stereo speakers.

Speaker configurations

Set up the system with the following speaker configurations:

Name	Speaker system
2-channel (stereo)	Left speaker and right speaker.

Audio jack	Headphones/2-channel
	Audio Out
	Mic In

A stereo speaker set is a left-right, two channel speaker system. A multi-channel audio speaker has a left-right front and left-right rear (surround) channel.

Connecting to speakers

Refer to the table below for the audio jacks on the left panel and their functions.

For stereo speakers or headphones

Audio jack	Description
	Connects to stereo speakers or headphones.

English

Configuring audio output settings

After connecting a speaker system to your All-in-one PC, follow the steps below to configure the speaker settings:

1. Right-click the speaker icon in the Windows® notification area and click **Sounds**.



2. Select a playback device and click **Properties** to configure the settings.



3. Do the advanced configurations, such as adjusting the speaker level and output rate. Click **OK** to finish the configurations.



Overclocking your All-in-one PC

1. Click the **S.H.E.** button on the speedometer on the desktop.

2. The system will restart automatically to finish the overclocking process. Click **OK** to continue.



3. The pointer will move from **High** to **Super** as shown.

Click the **S.H.E.** button again to undo the overclocking configuration.

English

Replacing or upgrading memory

Additional memory will increase application performance by decreasing hard disk access. **Visit an authorized service center or retailer for information on memory upgrades for your All-in-one PC.** Only purchase expansion modules from authorized retailers of this All-in-one PC to ensure maximum compatibility and reliability.

WARNING! Disconnect all the connected peripherals, any telephone or telecommunication lines and power connector (such as external power supply, battery pack, etc.) before installing or removing a memory.

1. Press the retaining clip and lift up the memory door.



2. Unscrew and remove the metal plate cover.



3. Removing or installing the memory based on your needs as instructed bellow.



Visit the ASUS support site at http://support.asus.com for the latest memory QVL.

Recovering your system

Using the hidden partition

The recovery partition includes an image of the operating system, drivers, and utilities installed on your system at the factory. The recovery partition provides a comprehensive recovery solution that quickly restores your system's software to its original working state, provided that your hard disk drive is in good working order. Before using the recovery partition, copy your data files (such as Outlook PST files) to a USB device or to a network drive and make note of any customized configuration settings (such as network settings).

Recovering the OS to the Factory Default Partition (F9 Recovery)

1. Disable **Boot Booster** in BIOS setup.
2. Press [F9] during bootup.
3. Select **Windows setup [EMS Enabled]** when this item appears and press [Enter].
4. Select the language and click **Next**.
5. Select **Recover the OS to the Default Partition** and click **Next**.
6. The factory default partition will be displayed. Click **Next.**
7. Data on the default partition will be cleared. Click **Recover** to start the system recovery.

You will lose all your data on the selected partition. Ensure to back up your important data beforehand.

8. When the recovery is completed successfully, click **Reboot** to restart the system.

Backing up the Factory Default Environment Data to a USB Drive (F9 Backup)

1. Repeat the step 1—4 in the previous section.
2. Select **Backup the Factory Environment to a USB Drive** and click **Next**.
3. Connect a USB storage device to your PC to start the Factory Default Environment backup.

The required size of the connected USB storage device should be larger than 5GB. The actual size may vary with your PC model.

4. Select a desired USB storage device if more than one USB storage device is connected to your All-in-one PC and click **Next**.

If there is already a partition with proper size in the selected USB storage device (for example, a partition that has been used as the backup partition), the system will show this partition automatically and reuse it for backup.

5. Based on the different situations in the previous step, data on the selected USB storage device or on the selected partition will be cleared. Click **Backup** to start backup.

> You will lose all your data on the selected USB storage device or on the selected partition. Ensure to back up your important data beforehand.

6. When backing up the factory default environment is completed successfully, click **Reboot** to restart the system.

Using the USB storage device (USB Restore)

When the Recovery Partition in your system is crashed, use the USB storage device to restore the system to the factory default partition or the factory environment data to the entire hard disk.

1. Disable **Boot Booster** in BIOS setup.
2. Connect the USB storage device that you back up the factory environment data to.
3. Press <ESC> on bootup and the **Please select boot device** screen appears. Select USB: XXXXXX to boot from the connected USB storage device.
4. Select the language and click **Next**.
5. Select **Restore** and click **Next**.
6. Select a task and click **Next**. Task options:

   - **Restore the OS to the Default Partition only**

     Select this option if you simply want to restore the OS to the factory default partition. This option deletes all data on the system partition "C" and keeps the partition "D" unchanged. After you click **Next**, the factory default partition will be displayed. Click **Next** again.

   - **Restore the Whole Hard Disk**

     Select this option if you want to restore your All-in-one PC to the factory default state. This option deletes all data from your hard disk and creates a new system partition as drive "C", an empty partition as drive "D" and a Recovery Partition.

7. Data on the factory default partition or on the whole hard disk will be cleared depending on the option you selected in the previous step. Click **Restore** to start the task.
8. When the restore is completed successfully, click **Reboot** to restart the system.

Manufacturer	ASUSTek COMPUTER INC.
Address, City	No. 150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN R.O.C
Country	TAIWAN
Authorized Representative in Europe	ASUS COMPUTER GmbH
Address, City	HARKORT STR. 21-23, 40880 RATINGEN
Country	GERMANY